



Wi-Fi Connect User Manual








This description is applied to appliance with Wi-Fi function.

Please read the manual carefully before using the product and keep it for future reference.

Note: Only for portable appliance



Let's get start!

 $Operation\ guideline.\ Please\ take\ below\ simple\ guideline\ instruction\ as\ reference.$

Operation Steps	Operation Items	New Account	Re-install APP (registered before)
Step 1	Download and Install APP	YES	YES
Step 2	Registration Account	YES	NO
Step 3	Login	YES	YES
Step 4	Add Device to control	YES	Registered Device will
			remain.

- If the appliance have the Wi-Fi function , the transmission power: less than 20dBm, and the radio frequency range is: 2412MHz-2472MHz.
- The appliance is compliant with the RE Directive (2014/53/EU).

Wi-Fi Module specification and basic information


1.Minimum specifications on a Smart phone: Android 5.0 version or higher

IOS 10.0 version or higher

2.Basic parameters for Wi-Fi:

Parameters	Details
Network frequency	2.400 - 2.500GHz
Standards of WLAN	IEEE 802.11 b/g/n(channels 1-14)
Protocol stack support	IPv4/IPv6/TCP/UDP/HTTPS/TLS/Multicast DNS
Security support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP

3.Wi-Fi module reset method On control panel, please press the "FAN" button 6 times within 4 seconds.



Download and Install the App

Method1: Please scan the QR code with a browser scanner, download and install the APP.



Method2:

For Android smart phone, open the Google "Play Store" on your smart phone and search "SmartLife-SmartLiving", download and install the APP.



For IOS smart phone, open the Apple "App Store" on your smart phone and search "SmartLife-SmartLiving", download and install the APP.





∕!\Note:

Alternatively, you could also download the "TUYA Smart" application which is also compatible, but has some slight differences in the layout and functions Please enable the permissions of Storage/Location/Camera for this APP when installing. Otherwise it will have some problems when operating.


Registration

- 1.If you don't have any account please tap button "Sign Up". 2.Read the Privacy Policy and tap "Agree".












- 4.Enter your E-mail address.5.Tap the button "Get verification code".



Registration

- 6.Enter the verification code you received from E-mail. 7.Set the Password with 6-20 characters including characters and numbers. 8.Tap "Done".






Log in

- 1.If you already have account, tap "Log in". 2.Enter your registered account and password. 3.Tap "Log in" button.







Forgot the password

If you forgot the password or you want to reset the password, operate as below:

- 1.Tap "Forgot password".2.Enter your account(E-mail address) and tap button "Get verification code".
- 3.Enter the verification code received by your E-mail.
- 4.Set the new password and tap button "Done".











Add device


There are 2 methods to add the device. **1-CF mode**1.1 Click "+" in the upper right corner of the "Home" screen or tap "Add device" on the room which has no device.



- 1.2 Tap the "Large home appliances" logo. 1.3 Tap the "Air conditioner(Wi-Fi)" logo.




1.4 Input the password of the Wi-Fi which the same as your smart phone connected, then tap "Next".




1.5 Power on the appliances, no need to launch the appliances. Press the "FAN" button on the control panel 6 times within 4 seconds, until the LED screen show "CF", which can make Wi-Fi reset, there will be switch between "CF" and "AP" if press many times.

1.6 Follow the comments on the next screen to reset the Wi-Fi module, then check "Confirm the device is reset" and tap "Next".



Note: On top of the appliance, press the "FAN" button 6 times within 4 seconds, until the screen display "CF".


- 1.7 You can see the percent rate of connecting process, at the same time "PP", "SA", "AP" shining in turn on the appliances display. "PP" means "Searching the router". "SA" means "connected to the router". "AP" means "connected to the server".









- 2-AP mode2.1 Power on the indoor unit, no need to launch the appliance.2.2 Click "+" in the upper right corner of the "Home" screen or tap "Add device" on the room which has no device.




 $2.3\, Tap\, the\, \hbox{\tt "Large Home Appliances" logo} \,\, and \,\, the\, \hbox{\tt "Air conditioner (Wi-Fi)" logo}.$



2.4 Tap in the upper right corner and choose "AP Mode" then follow the comments on the screen to reset the Wi-Fi module then check "Confirm the device is reset" and tap "Next".





Note:

On top of the appliance, press the "FAN" button 6 times within 4 seconds, until the the screen display "AP".

- 2.5 Read the instruction carefully and tap "Connect now".2.6 In the network setting screen, select "SmartLife-***", and tap it to connect.






- 2.7 You can see the percent rate of connecting process, at the same time "PP",
- "SA", "AP" shining in turn on the appliances display.
- "PP" means "Searching the router".
 "SA" means "connected to the router".
- "AP" means "connected to the server".







Paring Process



<u></u> [F	Waiting pair after reset
8P	1) Hotspot connect mode 2) Access to the Internet
ρρ	Searching and try to connect
58	Connect sucessful

Trouble Shooting

Description	Analysis of cause	
appliance can't be configured successfully	Check the mobile connected WLAN router SSID and password is correct; Check whether there are additional settings of WLAN router as shown below. Firewall by router itself or by PC MAC address filtering Hidden SSID DHCP server Reboot WLAN router, mobile device and appliance (WLAN module) and connect appliance by CF mode again. Before rebooting, check nobody has already connected to same appliance.	
Mobile can't control appliance	1. When appliance (WLAN module) is rebooted and app displays device remove, ignoring this confirmation will lead to mobile device losing control permission of the appliance. You will need to connect the appliance by CF mode again. 2. In case of power failure, mobile device will lose control permission of appliance for 3 minutes after power failure. (Notification will now show up on the mobile device.) If you cannot control the app (appliance) even after power restored, you will need to connect the appliance by CF mode again.	
Mobile can't find appliance	 App display appliance Device offline. Please check the following conditions. The appliance has been reconfigured. Appliance out of power. Router out of power. Appliance can't connect to router. Appliance can't connect to network through the router. Mobile device can't connect to network. After adding the device, it disappears in device list. Hold and slide down to refresh the device list. If it has no change, shut down the app and start again. 	

